

#330 FLOATING CHLORINE/BROMINE DISPENSER

DIRECTIONS FOR USE:

For cap removal or replacing, align notch in cap with the 2 lines on body.

1. To unlock and remove cap, twist counter clockwise (see arrow on lid).
2. Fill dispenser with 1" or 3" trichlor or bromine tablets.
(NEVER MIX CHEMICALS) See warning on top of dispenser.
3. Replace cap by turning clockwise (see arrow on lid) until cap clicks into full lock position.
4. Adjust feed rate by turning bottom collar. The larger the opening the greater the feed rate.
Some experimentation may be required to achieve desired result.

Note: This is not a toy. It is recommended that dispenser be removed when pool is in use by children or a heavy bather load. If cap is not locked securely and dispenser tips over, tablets can fall out and bleach pool surface.

OPTIONAL SCREEN FOR VINYL LINER POOLS. PART #R18856 Fig. B

Remove cap and position screen inside chamber but, before filling with tablets. This will prevent small pieces of tablet from slipping through adjustment collar openings and bleaching liner.

OPTIONAL ACCESSORY LEASH. PART #R221270 Fig. C.

Used to prevent dispenser from floating away and keep it in a desired area of the pool.

Leash has a 36" cord and anchor plate with pressure sensitive pad to adhere to most surfaces.

Slip cord or cords through hole in center of cap and tie knot. To keep dispenser from moving at all, use additional Leash as shown in Fig. A.

REPLACEMENT LIDS AVAILABLE

#R18729B Fits "B" Body

#R18729 Fits earlier Model "A" Body

